Instruction Manual

1. Description:

The equipment is used as a termination point for the feeder cable to connect with drop cable in FTTx communication network system. The fiber splicing, splitting, and distribution can be done in this box, and meanwhile it provides solid protection and management for the FTTx network building.

2. Features:

- 1. Totally enclosed structure.
- 2. Material: PC+ABS, moisture proof, waterproof, dust-proof, anti-aging, protection level IP68.
- 3. Clamping, splicing, fixation, storage and distribution of feeder cable and drop cable are integrated.
- 4. The interior is equipped with 1 * 2 FTB + 1 * 8 PLC Splitter or 1 * 8 PLC Splitter, and the bottom cover is welded by ultrasonic welding, which is not detachable.
- 5. The box body can be wall mounted or derrick mounted, suitable for indoor and outdoor use

3. Specification:

1. Environmental requirement

Working temperature: -40 °C ~+85 °C Relative humidity: ≤85% (+30 °C) Atmospheric pressure: 70KPa~106Kpa

2. Main technical datasheet

Insertion loss: ≤0.3dB UPC return loss: ≥50dB APC return loss: ≥60dB

3. Thunder-proof technical datasheet


The insulation resistance between the grounding device and the metal parts of the box is no less than $2 \times 10^4 \,\mathrm{M}\Omega/500 \,\mathrm{V}$ (DC); IR $\geq 2 \times 10^4 \,\mathrm{M}\Omega/500 \,\mathrm{V}$.

The voltage resistance between the grounding device, and the boxand its metal parts is no less than 3000V (DC)/min, no puncture, no flashover; U≥3000V


4. Configuration table:


Table 1 Model and configuration

i and i and a different garage.			
Model	Size (Pic 1)	Max Capacity	Installation Size(Pic 2)
	A*B*C		D/E*F
8 CORE	179*171*66	1 * 2 FTB + 1 * 8 PLC	52/142*165
		Splitter or 1 * 8 PLC Splitter	










Pic 1 Box Size


Pic 2 Installation Size

Instruction Manual

5. Product cable ways:



Pic.3 1 * 2 FTB + 1 * 8 PLC Splitter Cable Ways



Pic.4 1 * 8 PLC Splitter Cable Ways


6. Installation:

1. Wall-mounted installation

Drill 3 holes into the wall based on the size in table 1, place the expansion bolt Φ 7.5*40, place the box to match up the holes and use bolt to fasten. (Pic 4)

2. Pole-mounted installation

Fix 1 set of the pole ring to the telecom pole (Pic 5)



Pic 4 Wall mounted installation

Pic 5 Pole mounted installation

7.Accessories:

- 1. Users' Manual*1
- 2.Pole Ring*1 (Option)